


### Analyze your Data

Analyze is the operation that inspects and inserts data into the Plantview project database. Every time you add, delete or edit data in the project data folder a new analysis is required.

#### Use Plantview Workspace


1.

Press **Functions/Analyze** to activate the analysis operation.




2.

Press the **Analyze** button to start the analysis.




3.

In ANALYZE mode press the **Refresh** button to see the status of the analysis. When the analysis is complete you will be notified. Depending on the project size processing may take some time to complete.



4.

Press on **Menu/Elements** to view the data that has been inserted into the project database



5.

In the ELEMENTS mode, the analyzed data can be viewed or renamed.

Attributes can be added such as dates, altitude, categories, or account exclusions.

Advanced Filters facilitate the selection and assignment of attributes.

